

Application Instructions For Decals



3311 N. 29th Avenue Phoenix Arizona 85017 Since 1962

602-252-4700

Fax 602-252-4795

www.MacDanielSigns.com

Wet Method Decals Over 12"x12" (The best way for any size)

Materials:

Squeegee or Credit Card
One 1 gallon bucket or spray bottle filled
with cold water in bucket on bottle.
Liquid household detergent.
Proper cleaning material;
Clean cloth, Pin or needle, Scissors.



1. Clean and dry the application surface.
2. Mark the desired decal position. If application surface carries hinges, door openings, or hardware, butt the decal and apply in smaller sections.
3. Prepare a wetting solution of 2 or 3 teaspoons of liquid household detergent (not soap) in one (1) Gallon of cold water.
4. With the decal face down, remove the backing paper slowly.
5. Using a sponge, flood the application surface and adhesive side of the decal with the wetting solution.
6. Position the decal and squeegee flat from top to bottom with light, overlapping strokes.
7. Dry entire area with a clean cloth and re-squeegee the decal with firm strokes working from the center outward toward each edge.
8. Allow to dry for twenty-four (24) hours and re-squeegee.
9. If air bubbles occur, puncture with a needle and smooth down with the squeegee.
(Ultimate adhesion will occur 24-48 hours after application.)

Removal :

The decal can be removed by inserting a sharp knife or razor under a corner of the decal and peeling the film very carefully. The decal may not peel completely, but should remove in fairly decent side strips. Any residual adhesive which might transfer to the application surface can be removed by picking with the pressure-sensitive side of the removed label. If this proves unsuccessful, a mild solvent may be used or prolonged soaking in solvents such as mineral spirits may be performed.

(check with paint dealer to be sure the solvent does not attack or damage the surface of the paint.)